

Vodavi STSe, XTS-IP and XTSc-IP

Programming Flexible Buttons

- Press **SPEED Button Twice**
- Press the button you would like to program (Please remember the button you press needs to be programmed as a flex button in programming)
- **Dial the desired code - “See Below” You will hear a confirmation code after you dial a code.**

Function	Code	Function	Code
Call Coverage - Non Ringing	647 + Station Number	Background Music	3 channels 632+(0, 1, 2, 3)
Call Coverage - Ringing	646 + Station Number	Headset Mode	634
Call Park Personal	438	Caller ID Display - Answered Calls	659
Caller ID Name/ Number	653	Caller ID Display - Unanswered Calls	635
Do not Disturb	631	HTP (8 button phone)	667
Last Number Redial	Speed + #	Name in Display	690
Page - All Call	700	Repeat Redial	643
Ring Tone	695 + Ring Code (00-36)	Station Numbers	3 Digits 100-195 4 Digits x100-x195 x= the site code 1, 2, 3 etc.....
UCD Group	550 - 565	Voice Button One Touch Record	649 + Voice Mail Group 440 or 441
Universal Day /Night Answer	#5	Voice Mail Pause/ Resume Record	655
Speed Dial Numbers	Speed + Bin location 9000 - 9019	Night Service	604
Clear Call Forwarding, DND, Personal Messaging	662	Conference (8 button phone)	624
Answering Machine Ring	654 + 0	Answering Machine Speaker	654 + 1

To Clear a Flex Button

- Press **Speed Button Twice**
- Press the button you would like to clear
 Press **Flash Key** - You will hear a confirmation code

If you have any questions please feel free to call us @ 303-688-6191.