

## Changing your Phone's Display Name on an SBX-IP 320

You can designate a "name" for you station. This name will appear on your display, as well as the display of any other station in your system that you call or that calls you.

1. Use ▲ on the Nav Button to access the Programming Menu
2. Press the **OK** soft button to select the BASIC PROGRAM option.
3. Make sure the STATION NAME PROGRAM option is selected.
4. Press the **OK** soft button to select the STATION NAME PROGRAM option

1. BASIC PROGRAM  
2. ADVANCED PROGRAM

OK



5. Enter the name you want to have appear on the display. (*See page 2 for instructions*)

1. STATION NAME PROGRAM  
2. RING PROGRAM

BACK OK



ENTER NAME ( )

BACK OK



6. Press **HOLD/SAVE** to save the entry.

The name will now appear on your display.

JAMES PAUL (T)  
DEC 03 08 02:34pm

PICKUP CONF REDIAL-->



## Entering Characters for Display Entries

In addition to using the dialpad to enter numbers on the display, you may need to use it to enter text when using various features that allow you to enter text on the display (ex: Station Name Programming, Pre-selected Messages, Phonebook entries, and Speed Dialing entries).

Use the table below to locate the letter, number, and symbol codes that allow you to enter text on your display.

**Example:** To enter the name MARY, you would use the dialpad to enter the number series: 61 (for M), 21 (for A), 73 (for R), and 93 (for Y).

Desired Character	Dialpad Equivalent	Desired Character	Dialpad Equivalent	Desired Character	Dialpad Equivalent
A	21	P	71	0	00
B	22	Q	72	1	01
C	23	R	73	2	02
		S	74	3	03
D	31				
E	32	T	81	4	04
F	33	U	82	5	05
		V	83	6	06
G	41				
H	42	W	91	7	07
I	43	X	92	8	08
		Y	93	9	09
J	51	Z	94		
K	52				
L	53				
		PERIOD	13		
M	61	SPACE	*1		
N	62	COLON	*2		
O	63	SEMICOLON	*3		

If you have any questions, please feel free to call us @ 303.688.6191

